



**PLANTATION**

— HARDWOOD FLOORS™ —

341 Bernoulli Circle, Oxnard CA 93030

Phone: (805) 981-8383 Fax: (805) 981-8377

## **TOUCH UP INSTRUCTIONS FOR AIR-DRIED POLYURETHANE FINISHES**

If scratches are to top surface finish only:

1. The entire damaged board must be touched up – not just the damaged area.
2. Very *lightly* sand the entire damaged board. Use 220 Grit sandpaper. Care must be taken not to burn through to the stain. You just want to “rough-up” the surface so the newly applied finish will adhere.
3. Thoroughly clean the board to remove all dust and dirt.
4. The board should be completely dry, then using either a foam or bristle brush, apply one coat of the finish provided.
5. Allow the finish to dry for 24 hours before use.

If damage goes through the finish to the underlying stain:

1. You will need a furniture touch-up marker – these can be purchased at most any home improvement or hardware store. Purchase a color as close to your stain color as possible. If an exact color match can't be found, then go with the closest, darker color shade available. Follow directions on the marker for use.
2. After marker is dry, if you need to touch-up the finish – follow the instructions above.